

WEIGHT INDICATOR

WIDRA W90

WIDRA SPRL

Rue Z Gramme, 26

Zoning « Les Plenneses »

4821 ANDRIMONT

Function keys



when this key is pressed, the display registers "0", which frees one of the stored entry weights by introducing the corresponding sequence number.

N.B.

All that you need to do is to log in **9999 + E**
in order to have a revolving memory print-out

<u>No</u>	<u>No suite</u>	<u>Kg</u>
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	0	0
28	0	0
29	0	0
30	0	0



for input weighing

F2

for output weighing

F3

for single weighing at the time of weighing on exit

F4

for alternating the serial number and clearing input weighing memories

F1 **Weighing on entry**

When the truck enters into the factory it drives on the platform. Place a ticket into the printer.

press key



On the display you can see the last product number preceded by **P**



If the proposed number is correct : press



If it is not correct : enter a new number +



On the display you can now see the last customer number preceded by **C**.



If the number proposed is correct : press

If it is not correct : enter a new number +.



The screen registers the weight and proceeds with the entry print-out. When the weight is **stable** and stores it in one of the 30 revolving memories under the serial n°. This memory will be cleared at the output weighing.

INPUT

DATE	25/09/92	
TIME	10:04	
SERIAL N	6	
PRODUCT CODE		25
CUSTOMER CODE	10	
WEIGHT	47100	"kg"

*******BASCULE WIDRA Andrimont 087/350772*******

N.B.

If all 30 memories are full, further input weighing on entry is **impossible**. The screen registers horizontal dashes during 1" when you press



In that case, you need to :

- proceed with weighing output

- cancel a memory, using key



- cancel all the memories using the sequence number, key.



F2 **Weighing output**

If a lorry which was weighed on entry returns to be weighed on exit.

Press key **F2**

The screen displays "0" preceded by the letter S (exit)



Take the weighing ticket printed at the time of weighing on entry, note the serial number and

- enter the ticket in the printer

- enter the serial number + **E**

INPUT		OUTPUT
DATE	25/09/92	25/09/92
TIME	10:04	10 :32
SERIAL N	6	6
PRODUCT CODE	25	
CUSTOMER CODE	10	
WEIGHT	47100 "kg"	51000 "kg"

*******BASCULE WIDRA Andrimont 087/350 772*******

The printer will print out the data of the weighing on the same ticket, but in the right-hand column, and will release an input memory to enable a further input weighing operation with this cleared memory.

If the serial number for the weighing on entry does not match with the one of the output weighing, the weighing operator has introduced the wrong serial number.

All weights are followed by the "kg" symbol in inverted commas, indicating that the weights have indeed been recorded the help of a weighing machine.

Repeat of output printing on entry printed ticket

Press 

The display screen indicates **S**, followed by **0** without the kg symbol.

Press  + 

The screen displays **T** followed by **0** with the flashing kg symbol.

Enter tare weight + **E** and the printer prints out particulars of the weighing on exit, indicating the symbol "**Pt**" to show that the tare was entered manually (keyboard).

The symbol kg without the inverted commas also denotes that the weights are not those recorded on the machine

F3

Single weighing operation

Manual introduction of the tare data enables a lorry to be weighed on exit without having been weighed on entry.

Press Key.

F 3

The screen displays « 0 » kg preceded by the letter « t » tare

t 0 kg

Enter the correct knowned tara value +

E

The printer will print out the weighing datas

OUTPUT

DATE 25/09/92

TIME 10:04

SERIAL N 6

WEIGHT 47100 "kg"

KNOWN TARA "Pt " 1000 kg

NET WEIGHT 3710 kg

***** BASCULE WIDRA Andrimont 087/350772 *****

N.B.

The kg symbol for the tare and the net weight is without the inverted commas, which means that the tare particulars were introduced manually.

The "PT" symbol also registers this.

F4 **Serial number**

This enables you to visualize or modify the serial number for the next weighing operation.

Press key



The display screen indicates the next serial number.



You can now : a) confirm this number by **E**

b) alter this number + **E**, which will cancel all entry weights data stored in the memories.

No	Serial n°	Kg
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	0	0
28	0	0
29	0	0
30	0	0

Special functions

Date - time

Enables you to adjust the date and time.

Press key



The display screen indicates the stored date preceded by **d** (date)

d 101292

You can now :

- a) confirm the data with **E**
- b) correct it + **E**

The screen will display the stored time preceded by **H**

H 1446

You can now :

- a) confirm the time with **E**
- b) correct it + **E**

Print-out without date - time particulars

Enables you to make print-outs without date and time particulars.

This function is cancelled once services are restored following a power out.

Press.



The display screen will indicate the stored date.

Instaed of entering the date, enter **O + E**.

Memory-stored data on weighing on entry

Enables you to print out memory-stored data on input weighing.

Feed an A4 sheet of paper into the printer.

Press **M + 9999 + E**.

The printer will print out memory-stored weighing data.

No	Serial n°	Kg
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	0	0
28	0	0
29	0	0
30	0	0

Deleting 1 memory

If one or more of the memories printed is no longer in use for ex. the truck left the factory without weighing it is possible to liberate this memory like this :

press **M** + serial number to delete in the memory + **E**

Ex: **M + 126 + E** :

<u>No</u>	<u>Serial N°</u>	<u>Kg</u>
1	125	1900
2	0	0
3	127	4020
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	0	0
28	0	0
29	0	0
30	0	0

If all the memories must be deleted press



(serail number modification).

No	Serial n°	Kg
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0
27	0	0
28	0	0
29	0	0
30	0	0

90 WEIGHT INDICATOR

N.B.


The new weighing machine in your possession is a precision instrument which must be treated accordingly. In order to ensure problem-free use over a period of years, you are advised to observe the pointers listed in the "maintenance" section.

This machine has been precision-regulated. You are requested to keep calibration values in a safe place so that you can pass them on to our technician at the time the machine is serviced, or in the event of a problem.

At 220 volts, the indicator performs a test of the display panel and indicates the following three (3) values before displaying particulars of the weight :


1103	n° of installed program (short while)
0-1-2- ---	
t 4752 kg	platform dead weight
o 4 kg	zero drift

If the indicator fails to register "0" with nothing on the weighing table, press key and it will return to zero if the weight is within the -1% to 3% of capacity zero.




Front view, consisting of :


20 keys



Left



when this key is pressed and when 1 gross weight is displayed the indicator is set at zero if the indication or accumulation is between + 3% and -1% of the bottom of the scale. The automatic tracking zero will remain at zero if the load is less than 0,4 of a step.



when this key is pressed when the weight on display is stable the positive weight displayed is regarded as a tare and is deducted from the weight shown by the scales and :

deletion of the symbol **B**

appearance of the symbol **NET**

appearance of the symbol




when this key is pressed once again, the tare is set at zero,
the gross weight is displayed on the indicator and :

appearance of the symbol



deletion of the other symbols



when this key is pressed, the displayed weight becomes 0 and the
kg symbol flashes, enabling you to :

a) press K "E" to get out of this function mode and redisplay
the gross weight

b) enter a tare + E, using the keyboard. This will be deducted
from the weight originally displayed with :

deletion of the symbol




appearance of the symbol





appearance of the symbol





When this key is pressed once again, the displayed weight becomes 0 and the kg symbol flashes, enabling operation (a) or (b) as described above to be performed.

 function key

Right

  for digital value entry

 press this key to cancel keyboard entry

 press this key to confirm keyboard entry



 function key

 function key


 function key

 function key

Green fluorescent display



= 1 automatic tare



= 1 manual (keyboard) tare

Rear view

comprises :


1 sector connector - with fuse and filter

Power supply must be 220 volts + max. 10%, - 15% with earth


Both must be very specific to the weighing system (most important).

The 220 volt power supply must be connected to the same source and the earth must be common to all appliances which run into the weighing system.

Load cell connector Siemens




Jaecger connector



1: Earth	5: Power +
2: Eearth	6: Signal +
3: Power supply -	7: Sense -
4: Signal -	8: Sense +

1 CENTRONIX connection (parallel) is used with 1 printer by means of a 25 transmitting cable type P.C.



Pin définition

Pin 1	- strobe
Pin 2	+ data bit 0
Pin 3	+ data bit 1
Pin 4	+ data bit 2
Pin 5	+ data bit 3
Pin 6	+ data bit 4
Pin 7	+ data bit 5
Pin 8	+ data bit 6
Pin 9	+ data bit 7
Pin 10	+ acknowledge
Pin 11	+ busy
Pin 12	+ p.end (out of paper)
Pin 13	+ select
Pin 14	- auto feed
Pin 15	- error
Pin 16	- initialize printer
Pin 17	- select input
Pin 18-19	- gound


RS 232 C connection is used with a printer by means of a triphase cable.

W90 -COM2

DB 25/M

PRINTER

DB25/M



W90 Indicator

Serial Printer

RS 422/485 connection to printer is type 2 or 4 threads.

Indicator

Printer

Pin 6 -
Pin 18 -
Pin 11 -
Pin 23 -

Tx + *
Tx - *
Rx +
Rx -



folowing periferal
RS 422/485-232

Indicator

P.C.

Pin 2
Pin 3
Pin 7

T x D
R x D
G N D

Pin 3
Pin 2
Pin 7

R x D
T x D
G N D

Connection of 2 threads with pins *

RS 232 C connection to a P.C.

Indicator

P.C.

Pin 2
Pin 3
Pin 7

T x D
R x D
G N D

Pin 3
Pin 2
Pin 7

R x D
T x D
G N D

COMMUNICATION

General format

Message from PC STX 01 XX ETX CS

Reply to an enquiry STX 01 SID +012250. ETX CS

Example < 02 > 0 1 D I <03> <13d>

STX character <02>

01 Indicator N° : to be placed in the configuration during
 calibration in position I (from 00 to 99)

XX 2 letters representing an enquiry or action :

DI	calls for display-registered value
DV	calls for display-registered value NOT rounded off
PB	calls fro gross weight
PT	calls for tare value
PN	calls for net weight
TA	fixes a tare (detaring)
DE	deletes tare
ZE	automatic zero tacking

ETX Character <03>

+ + or - sign

. decimal point always present

SID S if stable, I if unstable, D if saturated

CS XOR of all message bytes, including STX and ETX

Note

All values are rounded off to the nearest step except DV

Response time is no more than 0,4 seconds. Message response is cancelled in the event of a saturated display.

8 bit + 1 stop bit without parity, baud rate selectable on 1200 to 9600 baud by dil switch.

DIL SWITCH (in the indicator)

<u>SW1</u>	<u>SW2</u>	
ON	ON	1200baud
ON	OFF	2400 baud
OFF	ON	4800 baud
OFF	OFF	9600 baud


SW3 no action

SW4

ON automatic zero tracking
OFF no automatic zero tracking

Multi-station **RS 485** connection to a P.C.

Compulsory 2 wire connection



N.B. in machine programming, a different number needs to be given to each network machine.

Repeater

Electromagnetic type

connection idem printer RS 232/422/485

L.E.D. (OP5)type

Standard B.C.D. output 3 wire cable connection (3 X 0,5 = max.35 m)

Round connector

Pin 1	+ 5 v
Pin 2	date
Pin 3	clock
Pin 4	free

Installation of connection lines

1. Load cell

Use type LP/LIYMCY 7 x 0,75 mm².

The protective cable sheathing ensures major insensitivity to radiated disturbance.

Length without amplifier : 100 metres.

2. R.S. 232

This type of connection is permitted up to maximum distances of 100 metres and, in many cases, less than 100 metres; depending on the configuration (standard CCITT 24 v, maximum 15 metres!).

A single test at the customer's expense will be enough to determine the reliability of such a connection at distances of above 15 metres.

Transmission cable must be type TPVP, twisted and provided with protective sheathing (per pair).

3. RS 422/485

Transmission cable still type TPVP, twisted and provided with protective sheathing (per pair).

Beyond 100 metres, provision will need to be made for the inclusion of a line amplifier (repeater).

N.B.

Widra can supply you with these cables and advise on the approximative lengths required.

4. Cable installation

Cables must be correctly installed. Care must be taken to steer clear of any sources of interference, such as neon lighting tubes, transformers, engines lift etc...

All connections must be made inside splice boxes, which must remain accessible at all times.

5. Essential precautions

Many data-processing problems are due to variations in voltage and micro power cuts. Like all computerized systems, weight indicators are sensitive to this type of occurrence. In the event of a voltage variation of +/- 10%, we warmly advise you to connect up the whole network providing power from the computer and the indicator to voltage regulators with special reserved lines.

If you are using a P.C., it is essential to provide a NO BREAK system for the entire installation, so as to safeguard data during operation. In any case, you will need to provide a top quality common earth.

WIDRA accepts no liability for any abnormal or excessive electrical situations which may occur.

Resetting at zero

If the ->O<- button fails to reset the machine at zero with nothing on the weighing table, zero resetting can be achieved by doing the following :

- recording the displayed weight data

- cutting the power supply and then restoring it
- entering code " "

5	5
---	---

 while the figures are being run off
- the display screen's indicating the memorized tare
- increasing or decreasing this displayed weight value + E

N.B.

This is not the normal procedure : please warn us in time so that me may take the necessary action.

Error message

The following error messages are displayed in the event of abnormal functioning :

Err 101

Ram is not valid or calibration has not been carried out.

In that case, the system will continue blocked

Err 201

The bottom of the scale divided by the step is $> 4\ 000$

Err 300

The converter is overloaded

Err 101

Converter is damaged

Table of contents

2	Fonction keys
4	Weighbridge weighing : weighing on entry
6	weighing on exit
7	Repeat of output printing o entry printed ticket
8	Single wieghing operation
9	Serial number
10	Special functions
11	Print-out without date-time particular
12	Memory-stored data on weighing on entry
14	Deleting 1 memory
16	Instruction for the use of the widra type w 90 weight indicator
17	Front view
20	Green fluorescent display
21	Rear view
24	Communication
26	Repeater
27	Installation of connection lines
29	Resetting at zero
30	Error message